

CHOOSING THE RIGHT AREA RUG PAD

Surface	Rubber Anchor Rubber Anchor II	UltiMat	OptiMat	MagNet	SecureNet	NaturalNet	PadLock	GridLock	AirLock	WedLock
Hardwood* or Laminate	1	1	2	1	2	3	3	2	3	NA
Tile/Stone -glazed or sealed	1	1	2	1	2	3	3	2	3	NA
Tile/Stone -unglazed or unsealed	1	1	2	1	2	3	NA	NA	NA	NA
Resilient -Linoleum	1	1	2	1	2	3	3	3	3	NA
Resilient -Vinyl	NA	NA	NA	NA	NA	NA	3	1	2	NA
Carpet	NA	1	2	NA	NA	NA	NA	NA	NA	2
Radiant Heat**	2	3	3	1	2	3	3	2	2	NA
Rounds / Shapes	1	1	2	1	2	NA	NA	NA	NA	NA
Custom Sizes	1	1	2	1	2	NA	NA	NA	NA	NA

Guide

1= Best

2= Better

3= Good

NA= Not Applicable

* All newly finished floors should be fully cured prior to installation of any pad or rug.

** Radiant heat may cause premature aging of any rug pad. While UltiMat and OptiMat would be less susceptible to this aging, the high "R-value" (insulating properties) of these pads make them less desirable for the purposes of heating efficiently.

JADE